



IMPORTANT

PLEASE READ THIS NOTICE!!!

LOADING THE MAGAZINE

1. Release the clutch by pushing the button at rear of magazine.
2. Carefully wind the knob, at rear of magazine, CLOCKWISE until the follower stops in the feed lips.
3. Load the magazine with GOOD QUALITY, BRASS CASE 9MM AMUNITION *ONLY!*
4. Release the clutch.
5. Flip out the winding lever and wind CLOCKWISE (10 MAXIMUM OR LESS COMPLETE TURNS) (23 MAXIMUM OR LESS COMPLETE TURNS FOR THE 100 RD MAGAZINE).
6. If magazine becomes difficult to load, release clutch as needed.

PLEASE READ AND FOLLOW YOUR
OWNERS MANUAL